

Specifications:

- Description With bracket
- In: 3/8", 5/16"
- Out: 3/8", 5/16", 3/16"

Features and Benefits:

- It is of great importance that all beer types are poured at the correct flow rate from the dispense tap.
- The Flow Controller can be adjusted by the technician on installation to ensure correct pour.
- Having set the flow rate the tamper evident device can be fitted to the controller to ensure the setting is not changed, without knowledge.
- All units are supplied with bracket and tamper evident device. Should the Flow Controller be required for a direct in line installation, remove the controller from wall bracket assembly.

